




MegaVise

PORTABLE VISE STAND



PM7050

OPERATORS MANUAL

Assembly • Operation • Parts List • Warnings • Warranty

Caution: Read all instructions carefully.

SAVE THESE INSTRUCTIONS. Refer to them often and use them to instruct others.

MANUEL DE L'UTILISATEUR

Assemblage • Fonctionnement • Liste de pièces • Avertissements • Garantie

Mise en garde : Lire attentivement l'ensemble des instructions.

CONSERVER CES INSTRUCTIONS. Les consulter souvent et les utiliser pour éduquer les autres.

MANUAL DEL OPERADOR

Ensamble • Operación • Lista de Partes • Advertencias • Garantía


Precaución: Lea cuidadosamente todas las instrucciones.

GUARDE ESTAS INSTRUCCIONES. Refiérase a las instrucciones y úselas para enseñarle a otras personas.

Congratulations

You have just purchased a Portamate PM7050 MegaVise Portable Vise Stand. This product has been specifically designed to assist you <<Need some description here of how the PM7050 helps>>.

Parts



Description	Part No.	Qty
A Top Frame	3100	1
B Straight Leg	3101	2
C Curved Leg	3102	2
D Outrigger Support	3103	2
E Support "T" Assembly	3104	2
F Roller Support with Flip-Stops	K103	2
G Roller Support Height Adjustment Knobs	G115	4
H Roller Support Adjustment Knob	G112	2
I 3-Point Knob	3105	4
J Right Axle Bracket	3106R	1
K Left Axle Bracket	3106L	1
L Axle Bolt – M6 x 45mm	D501	4
M Axle Nut – M6	D502	4
N Quick-Attach Machine Mounts	3042	2
O Carriage Bolts – M8 x 63mm	D503	4
P Washers – M8	D504	4
Q Lock Washer – M8	D505	4
R Nut – M8	D506	4
S 8" Wheels	3107	2
T Leg Plugs	G520	4
U Stock Supports	3108	2
V 3-Outlet Power Center	3109	1

Safety Rules

Using power tools of any kind can be dangerous if safe operating procedures are not followed. Recognizing the hazards of each tool and using them with respect and caution will considerably limit the possibility of personal injury. However, if safety precautions are ignored, personal injury will likely result. Always use common sense – your personal safety-is your responsibility.

1. Know your power tool. Read and understand the Owner's Manual and observe the warnings and instruction labels affixed to the tool.
2. Properly ground all tools.
3. Keep guards in place.
4. Remove adjusting keys and wrenches.
5. Keep work area clean and dry.
6. Keep children away.
7. Never leave running machines/tools unattended.
8. Disconnect tools from service.
9. Regularly maintain tools.
10. Use correct tools for the job.
11. Never force a tool.
12. Wear safety apparel.
13. Wear safety glasses/goggles.
14. Never stand or sit on tools.
15. Replace damaged components immediately.
16. Think Safety. Safety is a combination of operator awareness, common sense and alertness at all times.

Assembly Instructions

- 1** Open legs. Make sure pins snap into place.



- 2** Assemble foot brace as shown.



One Year Limited Warranty

Warrantor warrants to the original purchaser that the PortaMate PM7050 will be free from defects in materials and workmanship under normal use and service for a period of one (1) year from the date of original purchase.

The obligation of this Warranty is limited to repair or replacement, at our option, of components which prove defective under normal use.

Any product or component claimed to be defective should be sent during Warranty period, postage prepaid to **PortaMate, 332 E. Lincoln, Royal Oak, MI 48067, Attn: Warranty Department**, together with a copy of your original dated sales receipt. Call for authorization number before sending.

This warranty is in lieu of all other express warranties, obligations or liabilities. ANY IMPLIED WARRANTIES, OBLIGATIONS OR LIABILITIES, SHALL BE LIMITED IN DURATION TO THE ONE YEAR PERIOD OF THIS LIMITED WARRANTY. NO AGENT, REPRESENTATIVE, DEALER, OR EMPLOYEE OF THE COMPANY HAS THE AUTHORITY TO INCREASE OR ALTER THE OBLIGATIONS OF THIS WARRANTY.

This Warranty shall not apply to any product or component which in the opinion of the Warrantor has been modified or altered in any way, damaged as a result of an accident, misuse or abuse, or loss of parts. In no case shall the Warrantor be liable for any special or consequential damages, or any other costs or warranty, expressed or implied, whatsoever.

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Customer Service Department
248-399-6185 • 800-624-2027

www.portamate.com

